



Wisco Industries
Phone: 608-835-3106
Toll Free: 800-999-4726
Fax: 608-835-8273

VISIT OUR WEBSITE: www.thepizzaoven.biz

MODEL 690 SERIES THERMOSTAT REPLACEMENT KIT KIT #0016190SK

TOOLS NEEDED

- Phillips Screwdriver
- 1/16 inch Allen (hex) Wrench
- 9/16 Nut Driver or Wrench

PARTS INCLUDED

- Thermostat (Part #0016190)
- Wire (Part #0021196)

INSTALLATION INSTRUCTIONS

1. Unplug unit from outlet. Remove contents from the inside of the unit. Let cool.
2. Remove Door/s.
3. Tip unit on its back with the base controls facing up.
4. Remove 9 Phillips screws from the base plate, set base plate and screws aside.
5. Remove back plastic thermostat knob by using the 1/16 inch wrench (turn knob to off/low position.)
6. Remove the 9/16 inch thermostat mounting screw.
7. Unplug the 2 wires from the thermostat.
8. Reattach the 2 wires to the replacement thermostat.
9. Position the thermostat and remount using the 9/16 inch nut, tighten securely.
10. Remount the black plastic thermostat knob using the 1/16 inch Allen Wrench. Position so that the white line on the control knob is in the low/off position.
11. Attach the base plate and tighten all screws securely.
12. Tip the unit back on its feet and reattach the doors.
13. Plug unit in and adjust thermostat accordingly. Let unit warm up. Unit is now ready for operation.